

Series MGA Twin Cam

WORKSHOP MANUAL

NOTE

Refer to the end of the appropriate Section for the latest instructions when carrying out work on the vehicle.

Additional copies of this publication (Part No. AKD926B) can only be obtained from an M.G. Distributor.

Issued by

THE M.G. CAR COMPANY LIMITED

Proprietors: Morris Motors Limited

ABINGDON-ON-THAMES

Exported by

NUFFIELD EXPORTS LIMITED

Proprietors: Morris Motors Limited

COWLEY, OXFORD, ENGLAND



INTRODUCTION

This Manual has been prepared to provide the service operator with the necessary information for the maintenance and repair of the M.G. (Series MGA Twin Cam).

The Manual also serves as a ready-reference book for service supervision and covers items of procedure for the guidance of both the fully qualified and the less-experienced mechanic.

UNIT ARRANGEMENT

In the Manual the complete vehicle is divided into Sections each of which deals with an assembly or major component and carries a reference letter.

NUMBERING OF PAGES AND ILLUSTRATIONS

The pages and illustrations are numbered consecutively within each Section, and the Section title and letter are shown at the top of each page.


SERVICE TOOLS

Use of the correct tools contributes to an efficient, economic, and profitable repair. References have therefore been made to such tools throughout the Manual.

CONTENTS

General Data

Engine	• •	• •	• •	••			••	••	••	• •		A
Ignition Equipmen	nt		• •	••	• •	••	• •		••			Ī
Cooling System		• •		••		••						(
Fuel System	••	• •		••		••		• •				Ι
Clutch												E
Gearbox		••										F
Propeller Shaft												C
Rear Axle												F
Rear Road Spring	s			• •		.=.				• •	• •	I
Steering Gear												J
Front Suspension				••	••							K
Hydraulic Damper	rs											L
Braking System						••	• •	••	• •		• •	M
Electrical Equipme	ent					• •	• •					N
Wheels, Tyres, and	l Jacki	ing				• •					••	o
ubrication										••	••	P
Chassis					••		••				••	R
odv							- •		••	••	••	



THE M.G. (Series MGA Twin Cam) ENGINE

